

USER MANUAL Fixturlaser NXA GEOMETRY



Fixturlaser

Brand of ACOEM

CONTENT

Welcome to our world	1.1	Technical Specification TM & TS	20.1
Declaration of Conformity	2.1	Technical Specification BT2	21.1
Main Menu	3.1		
Straightness Measurement	4.1		
Rectangular Flatness Measurement	5.1		
Circular Flatness Measurement	6.1		
Memory Manager	7.1		
Receivers RM & RS	8.1		
Laser Transmitter T110	9.1		
Laser Transmitter T111	10.1		
Laser Transmitter T21	11.1		
Laser Transmitter T220	12.1		
Laser Modules TM & TS	13.1		
Wireless Module BT2	14.1		
Technical Specification RM & RS	15.1		
Technical Specification T110	16.1		
Technical Specification T111	17.1		
Technical Specification T21	18.1		
Technical Specification T220	19.1		

WELCOME TO OUR WORLD

Since the very beginning in 1984, ACOEM AB (formerly known as ELOS Fixturlaser AB) has helped industries throughout the world to achieve more profitable and sustainable production. We have reached where we are today by having the courage to think beyond the norm and follow slightly unconventional paths. We have had the courage to make mistakes and find new directions. Through our resolve, ambition and knowledge we have become a global player and a leader in innovative, user-friendly shaft alignment.

SUSTAINABLE INNOVATIONS

During our almost 30 years in this industry, we have explored, tweaked and tested more than anyone. Some might say we are incurable innovators whereas others might

say that we are highly focused. They both probably have a point. If we had not been devoted and ambitious, we would not have been the first in the industry to have a touch screen. Nor would we have been pioneers in the use of visible lasers and dual measurement heads.

Over the years, we have learnt to never compromise on quality and we are constantly in search of new, unexplored opportunities by combining advanced technology with design and function. By doing so, we have become the leading innovator in our industry. Not only do we minimize wear, production stoppages and costs, we also help save the environment. Natural resources are in short supply and if we can contribute to a more sustainable

world by making it a little bit straighter, we couldn't be happier.

TRUE COMMITMENT

One reason for our success is our solid commitment. We have ensured that we remain attentive to constantly pick up on the needs of the market. Our expert employees and dedicated dealers in over 70 countries are undoubtedly our most important asset. Satisfaction and team spirit are of particular importance to us and are consistently at the top of our priority list. With experience from a wide range of industries and manufacturing processes, we are fully aware of the problems and needs of our end-customers. We are passionate about what we do and we are driven by the desire to eliminate anything in the industry

worldwide that may be even slightly out of line.

PURE USABILITY

Our design and user-friendliness are carefully interwoven. As we develop new products, they also become cleaner, smarter, more functional and more robust. An industrial environment is demanding, infinitely more difficult to work in and inevitably subject to time pressure. There is no place for equipment with unnecessary functions, complicated interfaces and that is difficult to assemble.

Usability and user friendliness mean everything, not only to us but also to our customers. We have designed products that are easy to learn and can be incorporated quickly. By removing non-essential functions,

we make life less difficult for our users – and probably a little more difficult for our competitors.

END USER LICENSE AGREEMENT

The rights to use the software in this product are offered only on the conditions that you agree to all the terms stated below, i.e. the end user agreement. By using this product you agree to be bound by this agreement. If you do not accept this agreement your sole remedy is to return the entire unused product, hardware and software, promptly to your place of purchase for a refund.

The user is granted a single license to use the software contained in this product. Use is only permitted on the hardware it has been installed on at the time of purchase. The software may not be removed from the hardware.

The software contained in the system is the property of ACOEM AB, any copying or redistribution is strictly prohibited.

Modifying, disassembling, reverse engineering or decompiling the system or any part thereof is strictly prohibited.

Disclaimer of warranties: To the maximum extent permitted by applicable law, ACOEM AB and its suppliers provide the software contained in this product 'as is' and with all faults, and hereby disclaim all other warranties either expressed, implied or statutory.

Limited liability: No liability shall exceed the price of the product, and the sole remedy, if any, to any claim shall be a right of return and refund.

ACOEM AB or its suppliers shall, to the maximum extent permitted by applicable law, not be liable to any indirect, special, incidental, punitive, and consequential damages arising from the use of the system or any part thereof, authorized or unauthorized.

ACOEM AB (formerly known as Elos Fixturlaser AB) is since mid-2014 a fully owned subsidiary of ACOEM Group, headquartered in Lyon, France. Other brands within ACOEM Group are 01 dB, ONEPROD and METRAVIB. For more information please visit www.acoemgroup.com

DECLARATION OF CONFORMITY

In accordance with the EMC Directive 2004/108/EC, the Low Voltage Directive 2006/95/EC, including amendments by the CE-marking Directive 93/68/EEC & EC directives RoHS, 2011/65/EU.

Type of equipment

Alignment System

Brand name or trade mark

FIXTURLASER NXA Geometry

Type designation(s)/Model no(s)

I-0832 FIXTURLASER RM
I-0833 FIXTURLASER RS
I-0835 FIXTURLASER BT2
I-0390 FIXTURLASER T110

I-0285 FIXTURLASER T111
I-0897 FIXTURLASER T21
I-0289 FIXTURLASER T220
I-0836 FIXTURLASER TM
I-0837 FIXTURLASER TS

Manufacturer's name, address, telephone & fax no

ACOEM AB
Box 7
SE-431 21 Mölndal
Sweden

Tel: +46 31 7062800
Fax: +46 31 7062850

The following standards and/or technical specifications, which comply with good engineering practice in safety matters in force within the EEA, have been applied:

Standard/Test report/Technical construction file/Normative document

EN 61000-6-3:2007.

EN 61000-6-2:2005, EN 61000-4-2, -3, -4, -5, -6, -11.

EN 61010-1:2010

ISO9001:2008 Ref. No/ Issued by: DNV Certification AB Certification No. 2009-SKM-AQ-2704/2009-SKM-AE-1419.

The laser is classified in accordance with the International Standard IEC-60825-1:2014, USA FDA Standard 21 CFR, Ch I, Part 1040.10 and 1040.11 except for deviations

pursuant to laser notice No. 50, dated June 24, 2007.

The wireless device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions;

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Additional information

The product was CE-marked in 2013.

As manufacturer, we declare under our sole responsibility that the equipment follows the provisions of the Directives stated above.

Date and place of issue

Möln dal 2013-11-08

Signature of authorized person

A handwritten signature in black ink, appearing to read 'Hans Svensson', written in a cursive style.

Hans Svensson, Managing Director

MAIN MENU

The FIXTURLASER NXA is available with different programs for specific purposes. The programs included depend upon which application packages and accessories you have selected.



Press the ON button to start the system and the Main Menu appears.



In the Main Menu you can select the program that you want to use.

In the Main Menu you will also find the Memory Manager and Global Settings.

APPLICATION PROGRAMS



Shaft Alignment Horizontal
Machines



Shaft Alignment Vertical
Machines



Machine Train Alignment



Softcheck



Target Values



Hot Check



Straightness Measurement



Rectangular Flatness
Measurement



Circular Flatness
Measurement



Sensor Display



Text Editor



Machine Defined Data

MEMORY MANAGER



Memory Manager

SYSTEM FUNCTIONS



Global Settings



Bluetooth Indicator



Backlight



Battery Status



Off

STRAIGHTNESS MEASUREMENT

INTRODUCTION

In the Straightness Measurement program, straightness can be measured in two axes. The laser beam is used as reference and the deviation in distance between the laser beam and the measurement object is measured in two or more positions, with the use of the receiver.

MEASUREMENT METHODS

In the Straightness Measurement program, there are different measurement methods. Measurement method is selected in the measurement point window.



Standard Straightness

The laser beam is set roughly parallel to a surface or an object. Two points are used as references.



Straightness with the Clock method as reference

The laser beam is set roughly parallel to a centre line. Two points are used as references. The receiver is rotated 180

degrees in each measurement point to find the centre of the measurement object.



Straightness with the Arc Angle Method

The laser beam is set roughly parallel to a centre line. Two points are used as references. The receiver is placed in 3 to 9 positions at each measurement point to find the centre of the measurement object.



Rotate Laser Straightness

The laser transmitter is placed on the rotating object. The laser beam is adjusted until it is roughly collinear with the

axis of rotation. The receiver is fixated onto the measurement object and measurement points are taken while moving measurement object. At each measuring point, 2 recordings are done by rotating the laser beam 180 degrees.

Different measurement methods can be used in the same measurement.

MOUNTING

See chapters about receivers and laser transmitters.

CONNECTING RECEIVER

See chapter about wireless module.

STARTING THE PROGRAM




Start the program by touching the Straightness Measurement icon in the Main Menu.



Go to Settings for selecting settings.

SETTINGS



These settings are unique for this application.

For most of the settings, the current selection is shown in the icon.

The functions that are available depend upon which application packages and accessories you have selected.

Resolution shown



Opens window for selection of resolution shown.

Sampling time



Opens window for selection of sampling time.

A repeatability test can also be made here. See chapter “Repeatability test”.

Best fit



Opens window for selection of best fit type; Y axis only or Y and X axis.

Angle format



Opens window for selection of angle format.

Global settings




Opens Global settings. See chapter “Global settings”.

Confirm



Exits the Settings and returns to the application.

CONFIGURATION



Up to 99 points can be measured.

Number of points is selected by entering distances between them, starting from point 1.

Equal distances can be entered by entering them at the last point (the furthest from point 1). The same distance will then be filled in in all empty boxes towards point 1.

Enter distances



Touch and release the icon to enter distances.


Measure and enter distances between measurement points.

If most of the distances are unequal they can be entered one by one without exiting the input window, by changing the distance input to “next”.



Touch the icon to change distance input to “next”.

Tolerance




Opens window for selection of tolerance.

Notes



Opens Notes, where notes can be entered.



The selected area is marked in green.

Confirm configuration



Confirms the configuration and continues to summary screen.

Save configuration

The configuration (distances and tolerance) can be saved separately, to be opened up later.



Touch the save icon to save the configuration.

Change configuration

Distances can be changed.

300

Touch and release the icon to change a distance.

The last distance can be deleted if there are no measured points beyond it.




Touch the delete icon to remove a distance.


COARSE ADJUSTMENT

Standard Straightness

1. Position the laser transmitter at one end of the measurement object, on the object or on a tripod.
2. Position the receiver as close as possible to the laser transmitter. Adjust the height of the laser transmitter and the receiver until the laser beam hits the centre of the target.




3. Move the receiver as far from the laser transmitter as possible but still on the measurement object. Adjust the laser beam with the adjustment screws on the laser transmitter until it hits the centre of the target. Repeat until the laser beam hits the target at both ends of the measurement object.




Straightness with the Clock method

1. Locate the approximate centre of the bore with a tape measure and place the receiver at this centre.
2. Position the laser transmitter as close as possible to the first bore so that the laser beam hits the centre of the target.



3. Rotate the receiver 180° and slide it to correct half of the difference between the laser spot and the centre.



4. Adjust the laser transmitter so that the laser beam hits the centre of the target.

5. Move the receiver to the last bore.
Adjust the angle of the laser beam with the adjustment screws until it hits the centre of the target.




to the last measurement point and adjust the angle of the beam.

6. Move the receiver to the first measurement point.

If the laser beam does not hit the centre of the target, adjust the laser transmitter and then move the receiver


Straightness with the Arc Angle method

1. Place the laser transmitter as close as possible to the first bore. Make sure that the transmitter and its fixture is firmly attached to the casing.



2. Adjust the position of the laser, sideways and in height, until the laser beam is within 1-2 mm from the centre of the first reference bore, by using the

tape measure.



3. Adjust the angle of the laser beam, horizontally and vertically, by using the micrometer screws on the laser transmitter to position it in the centre of the second reference bore. Use a tape measure to position the beam into the centre within 1-2 mm.

4. If necessary, repeat the procedure for coarse adjustment until the beam is centred in both reference bores.

Rotate Laser Straightness

1. Mount the laser transmitter as close as possible to the center of the rotating reference object. Make sure that the laser transmitter is firmly fixated to the reference object.
2. Place the receiver on the measurement object and place it as close as possible to the laser transmitter and adjust its position until the laser beam hits the center of the target (within 1-2 mm).
3. Rotate the reference object with the laser 180 degrees. The laser beam will move during rotation and describe a half circle pattern. The center point of the line between the starting and end point will be the center of rotation.
4. Adjust the position of the laser vertically and horizontally until it hits the center of rotation (1-2 mm).
5. Move the measurement object as far as possible.
6. Mark the position where the laser beam hits the target. If the laser is outside the target, place a piece of paper board in front of it and make a mark.
7. Rotate the reference object 180 degrees. The laser beam will move during rotation and describe a half

circle pattern. The center point of the line between the starting and end point will be the center of rotation.

8. Adjust the angle of the laser beam with the two micrometer screws on the laser transmitter until it hits the center point.


REPEATABILITY TEST

Before starting the straightness measurement, we recommend that you perform a repeatability test. See chapter “Repeatability Test” in FIXTURLASER NXA manual.

Do the repeatability test at a position far from the laser transmitter.

MEASUREMENT

Summary screen



The summary screen shows all the measurement points.

The measurement point registration is done in the measurement point screen.

-  Touch and release a point to open the measurement point screen.

The touched point is marked in green.


If you want to change configuration, it is possible to return to the configuration.



-  Touch and release the configuration icon to go to configuration.

Measurement method



Measurement method is selected in the measurement point window.



Opens window for selection of measurement method. Standard Straightness, Straightness with the Clock method, Straightness with the Arc Angle method, or Rotate Laser Straightness.

Measurement point registration - Standard Straightness

Place the receiver on the point to be measured. Make sure that the laser beam hits the target.



Live values are indicated with a green vertical line beside the values.



Touch the register icon to register the measurement point.

The colour indicates the status of the Y and X values in relation to the selected tolerance.



Within tolerance.



Positive values within double tolerance.



Negative values within double tolerance.



Positive values out of double tolerance.



Negative values out of double tolerance.



When a measurement point is registered, fixed values are indicated without a green vertical line beside the values.

Note

A note with up to 20 characters can be entered at each point.



Touch the icon for entering a note.

Neighbor points

It is possible to continue directly to a neighbor point direct in the measurement point screen. In other words, it is not necessary to return to the summary screen between each point.

Touch a neighbor point to go to it.

-  Unmeasured neighbor point.
-  Measured neighbor point.

Remeasure a point



Touch the remeasure icon.

Delete a point



Touch the delete icon.

Return to summary screen



Touch the confirmation icon to return to summary screen.

Measurement point registration - Straightness with the Clock method

Using this method, the procedure at every measurement point is made in two steps.


For each measurement point, measurement values have to be taken in 2 positions.

Important: Make sure that the entire laser beam falls inside the detector area of the receiver at both positions, before starting the registration.

Note: The clock method with measurements only at 12 and 6 o'clock are not recommended for larger diameter bores (i.e. diameter over approximately 250 mm), or when there are worn surfaces in bottom of bores and/or errors in roundness.

Place the receiver upside-down and in level.






Live values are indicated with a green vertical line beside the values.



Register the values in the position before rotation. The Y and X values will be zeroed.

Rotate the receiver 180° (in level).





Register the values in the position after rotation. The Y and X values will be halved.

When a measurement point is registered, fixed values are indicated without a green vertical line beside the values. The colour indicates the status of the Y and X values in relation to the selected tolerance.


Measurement point registration - Straightness with the Arc Angle method


Using the Arc Angle method, the procedure at every measurement point is made in several steps.

For each measurement point, measurement values have to be taken in 3 positions and can be taken in up to 9 positions.

Important: Make sure that the entire laser beam falls inside the detector area of the receiver at all positions, before starting the registration.

Place the receiver at the first position and make sure that it is properly attached to the surface.






Live values are indicated with a green vertical line beside the values.




Register the values at the 1st position, by touching the icon for registration of positions in the Arc Angle method.


Rotate the receiver to a 2nd appropriate position.




Minimum angle between positions is 30 degrees. Green sector show permitted positions. Red sector show forbidden positions.




Rotate the receiver to the 3rd appropriate position.



Register the values at the 2nd position.




Register the values at the 3rd position.



Rotate the receiver to another position or confirm Arc Angle measurement and show result for the point.



Finish Arc Angle measurement and show result for the point.



When the Arc Angle measurement is finished, a list of the values at each position is shown together with the result. This list will not be saved but it is possible to take a screen dump of it.

Fixed result values are indicated without a green vertical line beside the values. The colour indicates the status of the Y and X values in relation to selected tolerance.


Measurement point registration – Rotate Laser Straightness


Using this method, the procedure at every measurement point is made in two steps.

For each measurement point, measurement values have to be taken in 2 positions, before and after rotating the laser 180°.

Important: Make sure that the entire laser beam falls inside the detector area of the receiver at both positions, before starting the registration.

Place the laser (in level)









Live values are indicated with a green vertical line beside the values.



Register the values in the position before rotation.

Rotate the laser 180° (in level).





Register the values in the position after rotation.

When a measurement point is registered, fixed values are indicated without a green vertical line beside the values. The colour indicates the status of the Y and X values in relation to the selected tolerance.

REFERENCES

There are different ways to select references.

Manually selected reference points

One or two points that can be selected in the measurement point screen.



Select point as reference.

Best fit

Contrary to the selection of reference points, best fit is a function that can be enabled or disabled. The function calculates a reference line that minimizes the deviation from measured points. In straightness, a minimum of two measured points is required for the function to be accessible. When the function is enabled, it will

continuously recalculate a reference line or plane whenever the input parameters to the function are changed. These parameters are changed if a new point is measured, a point is remeasured, a measured point is removed or if a user given distance is changed. The best fit reference line will however not be recalculated if the user aligns a measured point.



Enable the best fit function.



Update best fit calculations.



Disable the best fit function.

MEASUREMENT RESULT

Summary screen



The summary screen shows all the measurement points.

The diagram scale is automatically adjusted according to the highest or lowest Y or X value.

The symbols indicate status of the measurement point.

- Values within tolerance.
- Positive values within double tolerance.
- Negative values within double tolerance.
- Positive values out of double tolerance.
- Negative values out of double tolerance.
- Unmeasured point.
- Reference point.

Tolerance, maximum and minimum values and the difference between the maximum and minimum values are also shown.

Measurement values for each point can be seen in the measurement point screen or in the list screen.



Touch and release a point to open the measurement point screen.



Touch the list icon to go to list.


Save measurement

The measurement can be saved anytime and be opened later.



Touch the save icon to save the measurement.

List screen



The screenshot shows a list of 13 measurement points. Each row contains a point number, a distance value, and two coordinate values (Y and X) followed by a note value. The table is scrollable, as indicated by a vertical scrollbar on the right. Below the table is a navigation bar with several icons: a back arrow, a pencil and eraser, a left arrow with three dots, a right arrow with three dots, and a folder icon.

		Y	X	
1	0	0.000	0.000	-0.5
2	200	-0.030	+0.013	-0.5
3	400	-0.029	+0.009	-0.5
4	600	-0.037	+0.018	-0.5
5	800	-0.082	-0.088	-0.5
6	1300	-0.120	-0.073	-0.5
7	1500	-0.119	-0.076	-0.5
8	1700	-0.149	-0.012	-0.5
9	1900	-0.103	-0.013	-0.5
10	2100	-0.063	+0.074	-0.5
11	2600	-0.031	-0.034	-0.5
12	2800	+0.023	+0.074	-0.5
13	3000	+0.057	+0.094	-0.5



Touch the summary screen icon to return to summary screen.

The list screen shows all the measurement points in a list with distances, values and notes if any.

The list can be scrolled up and down with a finger or by using the arrows at the right.

Evaluating the result

The result is presented in relation to the selected references. The direction is depending on how the receiver is placed. If the receiver is placed according to the mounting instructions, Y values are showing the vertical direction and X values the horizontal direction. In the vertical direction (Y), positive values mean that the measurement object at this point is higher than the reference line and negative values that the measurement object is lower than the reference line.


In the horizontal direction (X, looking at the receiver from the laser transmitter), positive values mean that the measurement object at this point is to the left and negative values that the measurement object is to the right.

These values are compared with the tolerance to determine whether correction is necessary. When a tolerance is selected, the symbols indicate if the values are within tolerance or not.


In the diagrams, upwards correspond to positive values.

ALIGNMENT

Select the point to be aligned in the summary screen.




Place the receiver on the point. Make sure that the laser beam hits the target.




Standard
Straightness



Straightness
with the
Clock
method



Straightness
with the
Arc Angle
method




Rotate
Laser
Straightness



Touch the alignment icon.

Note: Make sure that the receiver is placed in the correct position on the right point before confirming to go to live adjustment.



The actual values for the selected point go live and alignment can be made towards zero. Zero will be in accordance to selected references.

Adjust vertically and horizontally until the Y and X values for the selected measurement point are within tolerance.

The arrows show in which direction to adjust.



Confirm the alignment.


Note: Depending on your application, alignment at one point might affect other measurement points. It is therefore recommended to remeasure all points when all adjustments are made.

STRAIGHTNESS TARGET VALUES


The function Straightness Target Values makes it possible to enter Target Values at the measurement points in the Straightness program.



Touch the Target Value icon to enter Target Values.



Enter Target Values and confirm.



Entered Target Values are shown in the measurement screen.

A screenshot of a list view showing target values for a straightness function. The list has five columns: a row number, a value, a Y value, an X value, and a fourth value. The data is as follows:

		Y	X	
1	0	0.000	0.000	0.0
2	500	+0.097	-0.169	-0.1
3	1000	-0.001	-0.079	-0.1
4	1500	+0.097	+0.230	-0.1
5	2000	+0.100	-0.157	-0.1
10	4500	0.000	0.000	0.0

Below the list, there are icons for navigation and settings, including a folder icon on the right.

When the Straightness Target Value function is selected the Target Values are shown in the list (instead of notes).

OTHER FEATURES

Turn off X diagram

When measuring in the Y axis only, the X diagram can be turned off. The diagram scale will then be automatically adjusted according to the highest or lowest Y value only.



Turns off X diagram.

Sensor display

Sensor Display can be reached directly in the summary screen.



Starts Sensor Display.

See chapter "Sensor Display" in the FIXTURLASER NXA manual.

Reference Receiver

A reference receiver, a second receiver, is used in applications where you want to check that the reference, the laser beam, has not moved during the measurement sequence.

The reference receiver is normally mounted at far distance from the laser transmitter to more easily detect any movements of the laser.

When the laser beam is adjusted to its final position and the reference is established, the values from the reference receiver are set to zero in the Sensor Display. It is possible, at any time during the measurement, to enter the Sensor Display and check that the values are still zero.

RECTANGULAR FLATNESS MEASUREMENT

INTRODUCTION

In the Rectangular Flatness Measurement program a laser plane is used as reference. The deviation in distance between the laser plane and the measurement object is measured in one or more positions with the use of the receiver.

The laser plane can either be created by three reference points or by levelling, with the laser plane put in level and with one measurement point as reference.

MOUNTING

See chapters about the receiver and laser transmitters.

CONNECTING RECEIVER

See chapter about wireless module.

STARTING THE PROGRAM



Start the program by touching the Rectangular Flatness Measurement icon in the Main Menu.



Go to Settings for selecting settings.

SETTINGS



These settings are unique for this application.

For most of the settings, the current selection is shown in the icon.

The functions that are available depend upon which application packages and accessories you have selected.

Resolution shown



Opens window for selection of resolution shown.

Sampling time



Opens window for selection of sampling time.

A repeatability test can also be made here. See chapter “Repeatability test”.

Angle format



Opens window for selection of angle format.

Global settings





Opens Global settings. See chapter “Global settings”.

Confirm



Exits the Settings and returns to the application.

CONFIGURATION



Up to 15 x 10 points can be measured.

Number of points is selected by entering distances between them, starting from point A1.


Equal distances can be entered by enter them at the last point (the farthest from point A1). The same distance will then be filled in in all empty boxes towards point A1.

Enter distances




Touch and release the icon to enter distances.

Measure and enter distances between measurement points.



The selected area is marked in green.

Tolerance



Opens window for selection of tolerance.

Notes



Opens Notes, where notes can be entered.

Confirm configuration



Confirms the configuration and continues to summary screen.

Save configuration

The configuration (distances and tolerance) can be saved separately, to be opened up later.



Touch the save icon to save the configuration.

Change configuration

Distances can be changed.



Touch and release the icon to change a distance.

The last distance in the row or column can be deleted if there are no measured points beyond them.



Touch the delete icon to remove a distance.

COARSE ADJUSTMENT

Three reference points

1. Position the laser transmitter at one end of the measurement object, on the object or on a tripod.
2. Mark the measurement points and name them as they will be shown in the flatness software (A1, A2 etc).
3. Position the receiver as close as possible to the laser transmitter. Adjust the height of the laser transmitter and the receiver until the laser beam hits the centre of the target.
4. Move the receiver to a second point on the measurement object far from the transmitter. Adjust the angle of the laser beam, with one of the adjustment screws, until it hits the centre of the target.
5. Move the receiver to a third point on the measurement object in a direction perpendicular to the other two points far from the transmitter. Adjust the angle of the laser beam, with the second adjustment screw, until it hits the centre of the target.
6. Repeat the procedure until the laser beam hits the centre of the target at all three points. Check that the beam falls into the target centre at all measurement points before starting the flatness measurement.

One reference point – Levelling

To check how a surface is positioned according to level, it is necessary to set the laser plane in level. This is done by zeroing the levels with the micrometer screws.


REPEATABILITY TEST

Before starting the flatness measurement, we recommend that you perform a repeatability test. See chapter “Repeatability Test” in FIXTURLASER NXA manual.

Do the repeatability test at a position far from the laser transmitter.

MEASUREMENT

Summary screen




The summary screen shows all the measurement points.

The measurement point registration is done in the measurement point screen.

- Touch and release a point to open the measurement point screen.

The touched point is marked in green.


If you want to change configuration it is possible to return to the configuration.



Touch and release the configuration icon to go to configuration.

Measurement point registration

Place the receiver on the point to be measured. Make sure that the laser beam hits the target.



Live values are indicated with a green vertical line beside the values.



Touch the register icon to register the measurement point.

The colour indicates the status of the Y value in relation to the selected tolerance.



Within tolerance.



Positive values within double tolerance.




Negative values within double tolerance.



Positive values out of double tolerance.



Negative values out of double tolerance.



When a measurement point is registered, fixed values are indicated without a green vertical line beside the values.

Note

A note with up to 20 characters can be entered at each point.



Touch the icon for entering a note.

Neighbor points

It is possible to continue directly to a neighbor point in the measurement point screen. In other words, it is not necessary to return to the summary screen between each point.

Touch a neighbor point to go to it.

-  Unmeasured neighbor point.
-  Measured neighbor point.

Remeasure a point



Touch the remeasure icon.

Delete a point



Touch the delete icon.

Return to summary screen



Touch the confirmation icon to return to summary screen.

REFERENCES

There are different ways to select references.

Manually selected reference points

One or three points can be selected in the measurement point screen.



Select point as reference.

Reference points for positive values only

Selects reference points for positive values only. When selecting positive values only, suitable reference points are automatically selected. Can be selected in the summary screen. Use only after points has been measured.



Select reference points for positive values only.

Reference points for negative values only

Selects reference points for negative values only. When selecting negative values only, suitable reference points are automatically selected. Can be selected in the summary screen. Use only after points has been measured.



Select reference points for negative values only.

Best fit

Contrary to the selection of reference points, best fit is a function that can be enabled or disabled. The function calculates

a reference plane that minimizes the deviation from measured points. In flatness, a minimum of three measured points is required in order for the function to be accessible. It is also required that not all the measured points lie on a straight line in order for the function to be accessible. When the function is enabled, it will continuously recalculate a reference plane whenever the input parameters to the function are changed. These parameters are changed if a new point is measured, a point is remeasured, a measured point is removed or if a user given distance is changed. The best fit reference plane will however not be recalculated if the user aligns a measured point.



Enable the best fit function.




Update best fit calculations.



Disable the best fit function.

MEASUREMENT RESULT

Summary screen



The summary screen shows all the measurement points.

The symbols indicate status of the measurement point.

-  Values within tolerance.
-  Positive values within double tolerance.
-  Negative values within double tolerance.
-  Positive values out of double tolerance.
-  Negative values out of double tolerance.
-  Unmeasured point.
-  Reference point.
-  Inactive reference point.

Tolerance, maximum and minimum values and the difference between the maximum and the minimum values are also shown.

Measurement values for each point can be seen in the measurement point screen or in the list screen.



Touch and release a point to open the measurement point screen.



Touch the list icon to go to list.


Save measurement

The measurement can be saved anytime and be opened later.



Touch the save icon to save the measurement.

List screen



			Y	X		
A1	0	0	0.000	+0.359	-0.4	NW
A2	0	150	-0.026	-4.887	-0.3	
A5	0	500	+0.074	+0.244	-0.4	
A6	0	650	0.000	-0.079	-0.5	SW
B1	150	0	-0.035	-4.887	-0.4	
B2	150	150	+0.110	-0.959	-0.4	
B5	150	500	+0.112	-0.313	-0.4	
B6	150	650	+0.090	+0.245	-0.4	
C3	450	250	+0.124	-0.959	-0.4	
C4	450	400	+0.242	-0.130	-0.4	
D3	600	250	+0.176	-1.025	-0.4	
D4	600	400	+0.224	+0.226	-0.4	
E1	850	0	-0.120	-1.577	-0.4	



Touch the summary screen icon to return to summary screen.

The list screen shows all the measurement points in a list with distances, values and notes if any.

The list can be scrolled up and down with a finger or by using the arrows at the right.


Evaluating the result

The result is presented in relation to the selected references. The direction is depending on how the receiver is placed. If the receiver is placed according to the mounting instructions, Y values are showing the vertical direction. In the vertical direction (Y), positive values mean that the measurement object at this point is higher than the reference plane, and negative values that the measurement object is lower than the reference plane.


These values are compared with the tolerance to determine whether correction is necessary. When a tolerance is selected, the symbols indicate if the values are within tolerance or not.

ALIGNMENT

Select the point to be aligned in the summary screen.



Place the receiver on the point. Make sure that the laser beam hits the target.



Touch the alignment icon.

Note: Make sure that the receiver is placed in the correct position on the right point before confirming to go to live adjustment.



The actual Y value for the selected point goes live and alignment can be made towards zero. Zero will be in accordance to selected references.

Adjust vertically until the Y value for the selected measurement point is within tolerance.

The arrow show in which direction to adjust.



Confirm the alignment.

Note: Depending on your application, alignment at one point might affect other measurement points. It is therefore recommended to remeasure all points when all adjustments are made.

OTHER FEATURES

Sensor display

Sensor Display can be reached directly in the summary screen.



Starts Sensor Display.

See chapter "Sensor Display" in the FIXTURLASER NXA manual.

Reference Receiver

A reference receiver, a second receiver, is used in applications where you want to check that the reference, the laser beam, has not moved during the measurement sequence.

The reference receiver is normally mounted at far distance from the laser transmitter to more easily detect any movements of the laser.

When the laser beam is adjusted to its final position and the reference is established, the values from the reference receiver are set to zero in the Sensor Display. It is possible, at any time during the measurement, to enter the Sensor Display and check that the values are still zero.

CIRCULAR FLATNESS MEASUREMENT

INTRODUCTION

In the Circular Flatness Measurement program, a laser plane is used as reference. The deviation in distance between the laser plane and the measurement object is measured in one or more positions with the use of the receiver.

The laser plane can either be created by three reference points or by levelling, with the laser plane put in level and with one measurement point as reference.

MOUNTING

See chapters about the receiver and laser transmitters.

CONNECTING RECEIVER

See chapter about wireless module.

STARTING THE PROGRAM




Start the program by touching the Circular Flatness Measurement icon in the Main Menu.



Go to Settings for selecting settings.

SETTINGS



The settings are unique for this application.

For most of the settings, the current selection is shown in the icon.

The functions that are available depend upon which application packages and accessories you have selected.

Resolution shown



Opens window for selection of resolution shown.

Sampling time



Opens window for selection of sampling time.

A repeatability test can also be made here. See chapter “Repeatability test”.

Best fit



Opens window for selection of Best fit type.

Best fit based on all circles (ABC) or one circle (A, B or C).

Angle format



Opens window for selection of angle format.

Flange measurement



Opens window for activating or de-activating Flange measurement.

Global settings





Opens Global settings. See chapter “Global settings”.

Confirm



Exits the Settings and returns to the application.

CONFIGURATION



Up to 3 circles with 99 points on each circle can be measured.

Number of points is selected by entering diameters and number of points on a circle.

Enter diameters and number of points on a circle




Touch and release the icon to enter diameters.

Measure and enter diameters.




Touch the icon to enter number of points on a circle.



The selected area is marked in green.

Tolerance



Opens window for selection of tolerance.

Notes



Opens Notes, where notes can be entered.

Confirm configuration



Confirms the configuration and continues to summary screen.

Save configuration

The configuration (diameters number of points on a circle and tolerance) can be saved separately, to be opened up later.



Touch the save icon to save the configuration.

Change configuration

The diameters and number of points on a circle can be changed. When measurement point registration has started, number of points can only be changed to a multiple of the origin number of points.



Touch and release the icon to change a diameter.



Touch the icon to change number of points on a circle.

Circles can be deleted if there are no measured points on them.



Touch the delete icon to remove a circle.

COARSE ADJUSTMENT

Three reference points

1. Position the laser transmitter at one end of the measurement object, on the object or on a tripod.
2. Mark the measurement points and name them as they will be shown in the flatness software (A1, A2 etc).
3. Position the receiver as close as possible to the laser transmitter. Adjust the height of the laser transmitter and the receiver until the laser beam hits the centre of the target.
4. Move the receiver to a second point on the measurement object far from the transmitter. Adjust the angle of the laser beam with one of the adjustment screws until it hits the centre of the target.
5. Move the receiver to a third point on the measurement object in a direction perpendicular to the other two points far from the transmitter. Adjust the angle of the laser beam with the second adjustment screw until it hits the centre of the target.
6. Repeat the procedure until the laser beam hits the centre of the target at all three points. Check that the beam falls into the target centre at all measurement points before starting the flatness measurement.

One reference point – Levelling

To check how a surface is positioned according to level, it is necessary to set the laser plane in level. This is done by adjusting the micrometer screws on the laser transmitter and by using the built-in spirit level in both directions.


REPEATABILITY TEST

Before starting the flatness measurement, we recommend you to perform a repeatability test. See chapter “Repeatability Test” in the FIXTURLASER NXA manual.

Do the repeatability test at a position far from the laser transmitter.

MEASUREMENT

Summary screen




The summary screen shows all the measurement points.

The measurement point registration is done in the measurement point screen.

- Touch and release a point to open the measurement point screen.

The touched point is marked with green.


If you want to change configuration, it is possible to return to the configuration.



Touch and release the configuration icon to go to configuration.

Measurement point registration

Place the receiver on the point to be measured. Make sure that the laser beam hits the target.



Live values are indicated with a green vertical line beside the values.



Touch the register icon to register the measurement point.

The colour indicates the status of the Y value in relation to the selected tolerance.



Within tolerance.



Positive values within double tolerance.




Negative values within double tolerance.



Positive values out of double tolerance.



Negative values out of double tolerance.



When a measurement point is registered, fixed values are indicated without a green vertical line beside the values.

Note

A note with up to 20 characters can be entered at each point.



Touch the icon for entering a note.

Neighbor points

It is possible to continue directly to a neighbor point in the measurement point screen. In other words, it is not necessary to return to the summary screen between each point.

Touch a neighbor point to go to it.

-  Unmeasured neighbor point.
-  Measured neighbor point.

Remeasure a point



Touch the remeasure icon.

Delete a point



Touch the delete icon.

Return to summary screen



Touch the confirmation icon to return to summary screen.

REFERENCES

There are different ways to select references.

Manually selected reference points

One or three points can be selected in the measurement point screen.



Select point as reference.

Reference points for positive values only

Selects reference points for positive values only. When selecting positive values only, suitable reference points are automatically selected. Can be selected in the summary screen. Use only after points has been measured.



Select reference points for positive values only.

Reference points for negative values only

Selects reference points for negative values only. When selecting negative values only, suitable reference points are automatically selected. Can be selected in the summary screen. Use only after points is measured.



Select reference points for negative values only.

Best fit

Contrary to the selection of reference points, best fit is a function that can be enabled or disabled. The function calculates a reference plane that minimizes the

deviation from measured points. In flatness, a minimum of three measured points is required in order for the function to be accessible. It is also required that not all the measured points lie on a straight line in order for the function to be accessible.

When the function is enabled, it will continuously recalculate a reference plane whenever the input parameters to the function are changed. These parameters are changed if a new point is measured, a point is remeasured, a measured point is removed or if a user given distance is changed. The best fit reference plane will however not be recalculated if the user aligns a measured point.



Enable the best fit function.




Update best fit calculations.



Disable the best fit function.

MEASUREMENT RESULT

Summary screen



Summary screen with up to 16 points on a circle.


The summary screen shows all the measurement points.

The symbols indicate status of the measurement point.

- Values within tolerance.
- Positive values within double tolerance.
- Negative values within double tolerance.
- Positive values out of double tolerance.
- Negative values out of double tolerance.
- Unmeasured point.
- Reference point.
- (●) Inactive reference point.

Tolerance, maximum and minimum values and the difference between the maximum and the minimum values are also shown.

When there are more than 16 points on a circle, the points are shown with colour dots only.



Summary screen with more than 16 points on a circle and best fit.

Measurement values at each point can be seen in the measurement point screen or in the list screen.



Touch and release a point to open the measurement point screen.



Touch the list icon to go to list.


Save measurement

The measurement can be saved anytime and be opened later.



Touch the save icon to save the measurement.

List screen



The screenshot shows a list of 13 measurement points (A1 to A13) with columns for distance, value, and notes. The table is scrollable, as indicated by a vertical scrollbar on the right. Below the table are navigation icons: a back arrow, a pencil, a snowflake, a magnifying glass, and a folder.

A1	1100	0.0	-0.071	-0.995	-0.5
A2	1100	22.5	-0.171	-0.749	-0.5
A3	1100	45.0	-0.266	-1.406	-0.5
A4	1100	67.5	-0.332	-1.547	-0.6
A5	1100	90.0	-0.293	-0.884	-0.5
A6	1100	112.5	-0.074	-1.583	-0.5
A7	1100	135.0	-0.006	-1.922	-0.5
A8	1100	157.5	+0.023	-0.815	-0.5
A9	1100	180.0	+0.190	+0.293	-0.5
A10	1100	202.5	+0.226	-0.672	-0.5
A11	1100	225.0	+0.133	+1.049	-0.5
A12	1100	247.5	+0.105	+0.794	-0.5
A13	1100	270.0	+0.081	-1.372	-0.5



Touch the summary screen icon to return to summary screen.

The list screen shows all the measurement points in a list with distances, values, and notes if any.

The list can be scrolled up and down with a finger or by using the arrows at the right.


Evaluating the result

The result is presented in relation to the selected references. The direction is depending on how the receiver is placed. If the receiver is placed according to the mounting instructions, Y values are showing the vertical direction. In the vertical direction (Y), positive values mean that the measurement object at this point is higher than the reference plan, and negative values that the measurement object is lower than the reference plan.

These values are compared with the tolerance to determine whether correction is necessary. When a tolerance is selected, the symbols indicate if the values are within tolerance or not.

ALIGNMENT

Select the point to be aligned in the summary screen.



Place the receiver on the point. Make sure that the laser beam hits the target.



Touch the alignment icon.

Note: Make sure that the receiver is placed in the correct position on the right point before confirming to go to live adjustment.



The actual Y value for the selected point goes live and alignment can be made towards zero. Zero will be in accordance to selected references.

Adjust vertically until the Y value for the selected measurement point is within tolerance.

The arrow show in which direction to adjust.



Confirm the alignment.

Note: Depending on your application, alignment at one point might affect other measurement points. It is therefore recommended to remeasure all points when all adjustments are made.

FLANGE MEASUREMENT

Flange measurement is used when taper of a flange is to be measured.



When flange measurement is activated, an alternative list screen is shown.

In each row, the points at each circle position are shown next to each other. To their right, the taper is shown.

	Y _A	Y _B	Y _C	Δ _{B-A}	Δ _{C-B}	Δ _{C-A}	
1	0.0	-0.071	-0.102	0.000	-0.031	+0.102	+0.071
2	22.5	-0.171	-0.138	-0.123	+0.033	+0.015	+0.048
3	45.0	-0.266	-0.215	-0.185	+0.050	+0.031	+0.081
4	67.5	-0.066	-0.283	-0.079	-0.218	+0.205	-0.013
5	90.0	-0.293	-0.017	0.000	+0.276	+0.017	+0.293
6	112.5	-0.074	-0.052	-0.032	+0.022	+0.020	+0.042
7	135.0	-0.006	-0.064	-0.108	-0.058	-0.043	-0.102
8	157.5	+0.023	+0.108	+0.021	+0.085	-0.087	-0.002
9	180.0	+0.190	+0.224	+0.198	+0.034	-0.026	+0.008
10	202.5	+0.226	+0.250	+0.203	+0.024	-0.047	-0.023
11	225.0	+0.133	+0.220	+0.156	+0.087	-0.064	+0.023
12	247.5	+0.105	+0.119	+0.064	+0.015	-0.056	-0.041
13	270.0	+0.081	+0.012	0.000	-0.069	-0.012	-0.081

Example:

First row at 0.0°:

A1, B1, C1, A1-B1, B1-C1, A1-C1

Second row at 22.5°:

A2, B2, C2, A2-B2, B2-C2, A2-C2 etc

The taper can be shown in mm/mils or degrees/radians.

OTHER FEATURES

Sensor display

Sensor Display can be reached directly in the summary screen.



Starts Sensor Display.

See chapter "Sensor Display" in the FIXTURLASER NXA manual.

Reference Receiver

A reference receiver, a second receiver, is used in applications where you want to check that the reference, the laser beam, has not moved during the measurement sequence.

The reference receiver is normally mounted at far distance from the laser transmitter to more easily detect any movements of the laser.

When the laser beam is adjusted to its final position and the reference is established, the values from the reference receiver are set to zero in the Sensor Display. It is possible, at any time during the measurement, to enter the Sensor Display and check that the values are still zero.

MEMORY MANAGER

FILE MANAGER

See chapter “Memory Manager” in the FIXTURLASER NXA manual.

SAVE MEASUREMENT

See chapter “Memory Manager” in the FIXTURLASER NXA manual.


TRANSFER FILES TO A PC

See chapter “Memory Manager” in the FIXTURLASER NXA manual.

Note: Apart from the picture file (jpeg) and a text file (txt), there will also be a list file

(lst) in the PC for straightness and flatness measurements.

STRAIGHTNESS MEASUREMENT



The screen displays measurement results, distances*, tolerance, references, file name, date and time, serial number of the display unit, program and program version.

*) If the number of points exceeds 25, only the distance to the last point is shown.

It is possible to go directly to Straightness measurement to continue measuring. All measurement data will be uploaded.



Exits the measurement file.



Go to Straightness Measurement by touching this icon.

RECTANGULAR FLATNESS MEASUREMENT



The screen displays measurement results, distances, tolerance, references, file name, date and time, serial number of the display unit, program and program version.

It is possible to go directly to Rectangular Flatness Measurement to continue measuring. All measurement data will be uploaded.




Exits the measurement file.



Go to Rectangular Flatness Measurement by touching this icon.

CIRCULAR FLATNESS MEASUREMENT



The screen displays measurement results, diameters, number of points on a circle, tolerance, references, file name, date and time, serial number of the display unit, program and program version.

It is possible to go directly to Circular Flatness Measurement to continue measuring. All measurement data will be uploaded.



Exits the measurement file.



Go to Circular Flatness Measurement by touching this icon.

RECEIVERS RM & RS

Receivers with 2-axes detector and inclinometer.



The receivers for the FIXTURLASER NXA Geometry come in two versions, the RM and the RS. The RM is intended to be used as the principal measurement receiver and the RS as the additional stationary reference receiver.

Hence when both receivers are connected the values displayed and recorded by the measurement applications are those of the RM. The RS can be viewed by accessing Sensor Display from the summary screen.

Except for the name, the receivers are identical and if only an RS is connected it will act as the measurement receiver.

MOUNTING

Mounting to magnetic base

The receiver is mounted on the magnetic base with extension fixture together with the receiver adapter and the rods.

Mount the receiver to the receiver adapter with the supplied screws. Mount the rods to the magnetic base with extension fixture. Slide the receiver on to the rods, as shown in picture.

Note: Make sure that the receiver is properly locked in its position.



Mounting to the receiver fork

Mount the receiver to the receiver fork, as shown in picture.




Placing of the probe guide

Place the probe guide, as shown in picture.



Placing of the magnetic base for bores

Place the magnetic base for bores, with the axial guide attached to the edge, as in picture.



LASER TRANSMITTER T110

Battery powered laser transmitter of diode type with built-in micrometer screws for adjustment of the laser beam in horizontal and vertical level.



LEVELLING

Coarse adjustment



Untighten the lock ring.

Fine adjustment



Tighten the lock ring.

MOUNTING

Mounting to magnetic base

The T110 is mounted on the magnetic base together with the rod adapter, the rods and the universal bracket.

Mount the universal bracket to the T110 with the supplied screws. Mount the rod adapter on the magnetic base with the supplied screw. Attach the rods to the rod adapter, and then slide the universal bracket with the laser transmitter onto the rods, as shown in picture.



Mounting to the transmitter beam fixture

Mount the T1110 to the transmitter beam fixture, as shown in picture.




LASER TRANSMITTER T111

Laser transmitter of diode type with built-in micrometer screws for adjustment of the laser beam in horizontal and vertical level. The T111 is powered by the supplied AC-adapter (110/230 Volts).



LEVELLING

Coarse adjustment



Untighten the lock ring.

Fine adjustment



Tighten the lock ring.

MOUNTING

See T110.

LASER TRANSMITTER T21

Battery powered laser transmitter of diode type. The laser transmitter has a built-in angular prism in a turret allowing the creation of a 360° laser plane. Laser beam levelling can be made in the X and Y coordinates as well as parallel adjustments. The turret can easily be detached giving a laser beam perpendicular to the X-Y plane.



LEVELLING

Coarse adjustment



Untighten the lock ring.

Fine adjustment



Tighten the lock ring.

MOUNTING

Straightness

The T21 is mounted on the magnetic base together with the rod adapter and the rods.

Mount the rod adapter on the magnetic base with the supplied screw. Attach the rods, and then slide the T21 onto the rods, as shown in picture.



Flatness

The T21 can either be mounted on a magnetic base or on a tripod.


When using the magnetic base, mount the rod adapter on the magnetic base with the supplied screw. Attach the T21 onto the adapter with the two supplied screws, as shown in picture.



On a tripod, use the supplied screws to attach the T21.

CALIBRATION OF THE SPIRIT LEVELS



Position the T21 on a table with flat surface which is in level within 0.2 mm/m in both directions. Mark two positions for the receiver at a distance of 1 metre minimum from each other.



1. Min 1 metre between the detector positions.
2. Zero the levels with the micrometre screws.
3. Zero the value on the screen.
4. Read and note the displayed value.
5. Turn the T21 180°.
6. Turn the turret 180°.
7. Zero the levels with the micrometer screws.
8. Zero the value on the screen.
9. Read and note the displayed value.

The value at 9 should be the same (within 0.2 mm/m) as at 4 if the level for this axis is

correctly adjusted. Any difference is divided by two and then added to the lowest of these values, which results in the value R.



10. Adjust to the R value using the micrometer screws.
11. Check the zeroing, zero again and re-adjust to R if necessary.
12. Zero the level with the tool.
13. Turn the T2I 90°.
14. Turn the turret 90°.
15. Zero the level with the micrometer screws.
16. Adjust to the R value using the micrometer screws.
17. Check the zeroing.
18. Zero the level with the tool.

LASER TRANSMITTER T220

Battery powered laser transmitter of diode type with built-in spirit levels and an angular prism. It is equipped with micrometer screws for adjustment of the laser beam in horizontal and vertical level. The optical head can be rotated 360° in order to project a reference plane with the laser beam.





1. Turret with built-in angular prism.
2. Laser apertures.
3. Horizontal spirit levels with adjustment screws.
4. Protractor with 15° increment.
5. Vertical spirit levels with adjustment screws.
6. Knob for rotating of optical head.
7. Laser On/Off switch.
8. LED indicating laser transmitter activity.
9. Levelling, coarse adjustment. With lock ring.
10. Levelling, fine adjustment.
11. Direction selector for laser beam.
12. Vertical or horizontal mode by turning ring.

LEVELLING

Coarse adjustment



Untighten the lock ring.

Fine adjustment



Tighten the lock ring.

ROTATING OF OPTICAL HEAD

Coarse adjustment

Turn the knob to the right, to the red X.
This will release the fine tuning.

Rotate the optical head until the laser beam is close to the detector.

Fine adjustment

Turn the knob to the left, to the green check mark.
This will connect the fine tuning screw.

Use the fine tuning to get the laser beam in the center of the detector.




MOUNTING

Straightness

The T220 can either be mounted on a magnetic base together with the angular bracket or be mounted on a tripod.

Mount the angular bracket on a magnetic base or on a tripod. Mount the T220 to the angular bracket, as shown in picture. Use the supplied screws.



Flatness


The T220 can either be placed directly on the measurement object or be mounted on a tripod.

Mount the T220 on a tripod as shown in picture. Use the supplied screws.




CALIBRATION OF THE SPIRIT LEVELS

Position the T220 on a table with flat surface which is in level within 0.02 mm/m in both directions. Mark two positions for the detector unit at a minimum distance of 1 metre from each other.



1. Zero the levels with the micrometre screws.
2. Zero the value on the screen.
3. Read and note the displayed value.
4. Turn the T220 180° and turn the turret.
5. Zero the levels with the micrometer screws.
6. Zero the value on the screen.
7. Read and note the displayed value.

The value at 7 should be the same (within 0.02 mm/m) as at 3 if the level for this axis is correctly adjusted. Any difference is divided by two and then added to the lowest of these values, which results in the value R.



10. Zero the level with the tool.
11. Turn the T220 90° and turn the turret.
12. Zero the level with the micrometer screws.
13. Adjust to the R value using the micrometer screws.
14. Check the zeroing.
15. Zero the level with the tool.

8. Adjust to the R value using the micrometer screws.
9. Check the zeroing, zero again and re-adjust to R if necessary.

LASER MODULES TM & TS

Modules with laser transmitter of diode type with built-in screws for adjustment of the laser beam in horizontal and vertical level.



The laser modules come in two versions, the TM and the TS. The TM is intended to be used together with the receiver RM and the TS together with the receiver RS.

Except for the name, the laser modules are identical.

MOUNTING

The laser modules are mounted on the receivers RM & RS.

Mount the laser module on the receiver, as in picture.



The receiver together with the laser module is mounted on the V-block together with the receiver adapter and the rods.

The RM & TM should be mounted on the movable machine and the RS & TS on the stationary machine.

See also mounting in the chapter “Shaft Alignment Horizontal Machines” in the FIXTURLASER NXA manual.



Note: When using the “Detector holder 22 mm offset”, the distance has to be measured from the zero point according to the label.



WIRELESS MODULE BT2

Module with wireless transceiver and battery pack. The wireless module uses standard Bluetooth technology.



1. Battery status indicator.
 - a) Flashing red – low battery.
2. Status indicator.
 - a) Continuously green – ON and connected.
 - b) Flashing green – ON and trying to connect.
3. On/off button.
4. Battery compartment.

Bluetooth Settings is described in chapter “Global Settings” in the FIXTURLASER NXA manual.

TECHNICAL SPECIFICATION – FIXTURLASER RM/RS

RM: Part. No. I-0832

RS: Part. No. I-0833

Housing material	Anodized aluminum
Operating temperature	0 to 50°C (32 to 122°F)
Storage temperature	-20 to 70°C (-4 to 158°F)
Relative humidity	10 – 90%
Weight	116 g (4.09 oz)
Dimensions (with cable attached)	57 mm x 50 mm x 40 mm (2.2 in x 2.0 in x 1.6 in)
Dimensions (with wireless transmitter I-0835 attached)	124 mm x 50 mm x 40 mm (4.9 in x 2.0 in x 1.6 in)
Environmental protection	IP 65
Detector	2-axis PSD
Detector size	20 mm x 20 mm (0.8 in x 0,8 in)
Detector resolution	1 µm
Measurement accuracy	1% ± 3 µm
Ambient light protection	Optical filtering and ambient light signal rejection
Inclinometer resolution	0.1°

Inclinometer accuracy

$\pm 0.5^\circ$

TECHNICAL SPECIFICATION – FIXTURLASER T110

Part. No. I-0390

Housing material	Anodized aluminum
Operating temperature	0 to 50°C (32 to 122°F)
Storage temperature	-20 to 70°C (-4 to 158°F)
Relative humidity	10 – 90%
Weight	1100 g (2.43 lbs)
Dimensions	60 mm x 60 mm x 140 mm (2.4 in x 2.4 in x 5.5 in)
Laser	650 nm class II diode laser
Laser power	< 1 mW
Measurement distance	Up to 50 m (164 ft)
Power supply	2 batteries type LR6 (AA)
Warming up time	10 min
Operating time	15 hours

TECHNICAL SPECIFICATION – FIXTURLASER T I I I


Part. No. I-0285

Housing material	Anodized aluminum
Operating temperature	0 to 50°C (32 to 122°F)
Storage temperature	-20 to 70°C (-4 to 158°F)
Relative humidity	10 – 90%
Weight	1030 g (2.27 lbs)
Dimensions	60 mm x 60 mm x 140 mm (2.4 in x 2.4 in x 5.5 in)
Laser	650 nm class II diode laser
Laser power	< 1 mW
Measurement distance	Up to 50 m (164 ft)
Power supply	AC-adaptor 110/230 Volts
Warming up time	10 min

TECHNICAL SPECIFICATION – FIXTURLASER T2I

Part. No. I-0897


Housing material	Anodized aluminum
Operating temperature	0 to 50°C (32 to 122°F)
Storage temperature	-20 to 70°C (-4 to 158°F)
Relative humidity	10 – 90%
Weight	1150 g (2.54 oz)
Dimensions	100 mm x 103 mm x 109 mm (3.9 in x 4.0 in x 4.2 in)
Laser	650 nm class II diode laser
Laser power	< 1 mW
Measurement distance	Up to 20 m (66 ft)
Laser sweep flatness	±0.02 mm/m
Angular prism accuracy	±0.02 mm/m
Spirit level resolution	0.3 mm/m
Power supply	2 batteries type LR6 (AA)
Warming up time	10 min
Operating time	15 hours




TECHNICAL SPECIFICATION – FIXTURLASER T220

Part. No. I-0289

Housing material	Anodized aluminum
Operating temperature	0 to 50°C (32 to 122°F)
Storage temperature	-20 to 70°C (-4 to 158°F)
Relative humidity	10 – 90%
Weight	3500 g (7.72 lbs)
Dimensions	175 mm x 175 mm x 115 mm (6.9 in x 6.9 in x 4.5 in)
Laser	650 nm class II diode laser
Laser power	< 1 mW
Measurement distance	Up to 50 m (164 ft)
Beam deviation from levels	< 0.02 mm/m
Laser sweep flatness	±0.02 mm/m
Angular prism accuracy	±0.02 mm/m
Spirit level resolution	0.02 mm/m
Tilt adjustment from level	±15 mm/m
Power supply	4 batteries type LR6 (AA)
Warming up time	10 min
Operating time	15 hours





The built-in angular prism works as shown to the left. The incoming laser beam is deflected $90^\circ \pm 0.02$ mm/meter also if the beam hits the prism obliquely.

TECHNICAL SPECIFICATION – FIXTURLASER TM/TS

TM: Part. No. I-0836

TS: Part. No. I-0837

Housing material	Anodized aluminum
Operating temperature	0 to 50°C (32 to 122°F)
Storage temperature	-20 to 70°C (-4 to 158°F)
Relative humidity	10 – 90%
Weight	136 g (4.80 oz)
Dimensions	55 mm x 50 mm x 38 mm (2.2 in x 2.0 in x 1.5 in)
Laser	650 nm class II diode laser
Laser power	< 1 mW
Measurement distance	Up to 20 m (65 ft)
Warming up time	10 min

TECHNICAL SPECIFICATION – FIXTURLASER BT2

Part. No. I-0835

Housing material	Anodized Aluminium and PC/ABS plastic
Operating temperature	0 to 50°C (32 to 122°F)
Storage temperature	-20 to 70°C (-4 to 158°F)
Relative humidity	10 – 90%
Weight	90 g (6.7oz) with batteries
Dimensions	82mm x 50mm x 40mm (3.2in x 2.0 in x 1.6 in)
Wireless communication	Class II Bluetooth transmitter
Communication range	10 m (33 ft)
Power supply	3 AA (LR6) batteries
Operating time	10 hours continuously
LED indicators	Transmitter and battery status indicators



Publication No. P-0252-GB

© 2016 ACOEM AB, Mölndal, Sweden

All rights reserved. No part of this manual may be copied or reproduced in any form or by any means without prior permission from ACOEM AB

www.fixturlaser.com